

illume™ AC Driver Instructions

Thank you for your purchase. This manual describes how to connect your illumes to mains power.

CONTENTS


- 1 x AC Diver Module
- 1 x Power Module
- 1x Instruction Sheet

INSTRUCTIONS

1. Fit Power Module between the Solar Panel and the Control Module.
2. Connect the male cable from the solar panel to the female power module.
3. Connect the male cable from the AC Driver to the second female connection on the power module.
4. Follow flow of components as per the diagram.
5. Connect AC lead to standard 240v 10A general purpose outlet (GPO).
6. Note: The GPO must be installed by a licensed electrician within 1 metre of the illume panel


Note:

- AC Driver Option NOT suitable for retail illume models.**
- Component order recently changed. Please install as per the diagram.**



Not Supplied - Must be installed by a licensed electrician

WIRING DIAGRAM



2024 Kimberley Products. All rights reserved. In ongoing commitment to product quality, we reserve the right to change specifications without notice. E&OE.